

# SAMSUNG



Printed in Korea  
GH68-44126A Rev.1.0  
SEA Type 05/2015




# QUICK START GUIDE

EO-BG920

**SAMSUNG**

Level<sup>U</sup>

**SAMSUNG**



Copyright © 2015 Samsung Electronics America, Inc.

Bluetooth® is a registered trademark of Bluetooth SIG, Inc. worldwide.

- Please read this manual before using the device to ensure safe and proper use.

- Images may differ in appearance from the actual product. Content is subject to change without prior notice. You can access the full user manual for more information. Visit [www.samsung.com](http://www.samsung.com) to view device information, the user manual, and more.

## Device layout

<b>a</b>	Charger port	<b>g</b>	Multifunction/ Talk button
<b>b</b>	Microphone	<b>h</b>	Power switch
<b>c</b>	Neckband (Vibration area)	<b>i</b>	Rubber o-ring
<b>d</b>	Volume button	<b>j</b>	Left earphone
<b>e</b>	Notification light	<b>k</b>	Right earphone
<b>f</b>	Magnet		

## Charging the battery

Before using the headset for the first time, you must charge the battery.

Open the charging port cover and connect the headset to a computer or the USB power adapter via the USB cable.



- You can charge the headset using the charger (sold separately).
- The charger should remain close to the electric socket and easily accessible while charging.

## Turning the headset on or off

Slide the Power switch to turn on or off the headset.



When you turn on the headset for the first time, it enters Bluetooth pairing mode.

## Connecting devices via Bluetooth

You can receive incoming calls or listen to multimedia files when your headset is connected to Bluetooth-enabled devices.

1. Turn on the headset, and then press and hold the Multifunction button for about three seconds to enter Bluetooth pairing mode. The notification light flashes red and blue.
2. On your other device, activate the Bluetooth feature and tap **Samsung Level U** from the list.

## Connecting additional devices

The headset can connect to up to two Bluetooth-enabled devices at the same time. For more information, refer to the user manual.

## Safety information

Read all safety information before using the device to ensure safe and proper use. To view the full safety information, refer to the Samsung website.

**The headset contains magnets in its earbuds. The American Heart Association (US) and the Medicines and Healthcare Products Regulatory Agency (UK) both warn that magnets can affect the operation of implanted pacemakers, cardioverters, defibrillators, insulin pumps or other electro medical devices (collectively, "Medical Device") within the range of 15 cm (6 inches). If you are a user of any of these Medical Devices, DO NOT USE THE HEADSET UNLESS YOU HAVE CONSULTED WITH YOUR PHYSICIAN**

**Use manufacturer-approved batteries, chargers, accessories, and supplies**

**Do not touch the device with wet hands**

**Do not drop or cause an impact to the charger or the device**

**Do not bend or twist the device excessively**

**Do not store your device in very hot or very cold areas. It is recommended to use your device at temperatures from 5°C to 35°C**

**Do not allow children or animals to chew or suck the device**

**Do not disassemble, modify, or repair your device**

**Do not use a headset while driving or riding. Doing so may distract your attention and cause an accident, or may be illegal depending on your region**



To prevent possible hearing damage when using a headset, do not listen to sound at high volume for long periods.

## **FCC Part 15.19**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## **FCC Part 15.21**

Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

## **FCC RF Exposure Statement**

This equipment complies with FCC RF Radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

## **Recycling Direct**

To dispose electronics properly, follow the recycling process regulated in your area or go to Samsung website to find the nearest recycling location:

*[www.samsung.com/recyclingdirect](http://www.samsung.com/recyclingdirect)*

Or call, (877) 278 – 0799.

## **Samsung Electronics America, Inc**

85 Challenger Road,

Ridgefield Park, New Jersey, 07660

Phone: 1-800-SAMSUNG (726-7864)



## Warranty Information

SAMSUNG ELECTRONICS AMERICA, INC.  
("SAMSUNG") warrants that SAMSUNG's devices and accessories ("Products") are free from defects in material and workmanship under normal use and service.

Samsung Electronics America, Inc.

85 Challenger Road

Ridgefield Park, New Jersey 07660

Phone: 1-800-SAMSUNG (726-7864)

## Standard Limited Warranty

### What is covered and for how long?

The warranty period commences upon the date of purchase by the first consumer purchaser and continuing for the following specified period of time after that date:

Device	1 Year
Battery(ies)*	1 Year
Other Accessories*	1 Year

\*If applicable.

## What is not covered?

This Limited Warranty is conditioned upon proper use of the Product.

This Limited Warranty does not cover: (a) defects or damage resulting from accident, misuse, abnormal use, abnormal conditions, improper storage, exposure to liquid, moisture, dampness, sand or dirt, neglect, or unusual physical, electrical or electromechanical stress; (b) scratches, dents and cosmetic damage, unless caused by SAMSUNG; (c) defects or damage resulting from excessive force or use of a metallic object when pressing on a touch screen; (d) equipment that has the serial number or the enhancement data code removed, defaced, damaged, altered or made illegible; (e) ordinary wear and tear; (f) defects or damage resulting from the use of Product in conjunction or connection with accessories, products, or ancillary/peripheral equipment not furnished or approved by SAMSUNG; (g) defects or damage resulting from improper testing, operation, maintenance, installation, service, or adjustment not furnished or approved by SAMSUNG,

including but not limited to installation of unauthorized software and unauthorized root access, both of which shall void this limited warranty; (h) defects or damage resulting from external causes such as collision with an object, fire, flooding, dirt, windstorm, lightning, earthquake, exposure to weather conditions, theft, blown fuse, or improper use of any electrical source; (i) defects or damage resulting from cellular signal reception or transmission, or viruses or other software problems introduced into the Product; or (j) Product used or purchased outside the United States. This Limited Warranty covers batteries only if battery capacity falls below 80% of rated capacity or the battery leaks, and this Limited Warranty does not cover any battery if (i) the battery has been charged by a battery charger not specified or approved by SAMSUNG for charging the battery; (ii) any of the seals on the battery are broken or show evidence of tampering; or (iii) the battery has been used in equipment other than the SAMSUNG device for which it is specified.

## **What are SAMSUNG's obligations?**

During the applicable warranty period, provided the Product is returned in accordance with the terms of this Limited Warranty, SAMSUNG will repair or replace the Product, at SAMSUNG's sole option, without charge. SAMSUNG may, at SAMSUNG's sole option, use rebuilt, reconditioned, or new parts or components when repairing any Product, or may replace the Product with a rebuilt, reconditioned or new Product.

Repaired/replaced cases, pouches and holsters will be warranted for a period of ninety (90) days. All other repaired/replaced Products will be warranted for a period equal to the remainder of the original Limited Warranty on the original Product or for ninety (90) days, whichever is longer. All replaced Products, parts, components, boards and equipment shall become the property of SAMSUNG. Except to any extent expressly allowed by applicable law, transfer or assignment of this Limited Warranty is prohibited.

## **What must you do to obtain warranty service?**

To obtain service under this Limited Warranty, you must return the Product to an authorized phone service facility in an adequate container for shipping, accompanied by the sales receipt or comparable proof of sale showing the original date of purchase by the first consumer purchaser, the serial number of the Product and the seller's name and address.

To obtain assistance on where to deliver the Product, please call SAMSUNG Customer Care at 1-888-987-4357. If SAMSUNG determines that any Product is not covered by this Limited Warranty, you must pay all parts, shipping, and labor charges for the repair or return of such Product.

You should keep a separate backup copy of any contents of the Product before delivering the Product to SAMSUNG for warranty service, as some or all of the contents may be deleted or reformatted during the course of warranty service.

## **What are the limits on SAMSUNG's liability?**

THIS LIMITED WARRANTY SETS OUT THE FULL EXTENT OF SAMSUNG'S RESPONSIBILITIES, AND THE EXCLUSIVE REMEDY REGARDING THE PRODUCTS.

ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL SAMSUNG BE LIABLE FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT OR FOR, WITHOUT LIMITATION, COMMERCIAL LOSS OF ANY SORT; LOSS OF USE, TIME, DATA, REPUTATION, OPPORTUNITY, GOODWILL, PROFITS OR SAVINGS; INCONVENIENCE; INCIDENTAL, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES; OR DAMAGES ARISING FROM THE USE OR INABILITY TO USE THE PRODUCT. SOME STATES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, OR THE DISCLAIMER OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS AND DISCLAIMERS MAY NOT APPLY TO YOU.

SAMSUNG MAKES NO WARRANTIES OR REPRESENTATIONS, EXPRESS OR IMPLIED,

STATUTORY OR OTHERWISE, AS TO THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE OR SUITABILITY OF ANY THIRD-PARTY SOFTWARE OR EQUIPMENT USED IN CONJUNCTION WITH THE PRODUCT, OR THE ABILITY TO INTEGRATE ANY SUCH SOFTWARE OR EQUIPMENT WITH THE PRODUCT, WHETHER SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT IS INCLUDED WITH THE PRODUCT DISTRIBUTED BY SAMSUNG OR OTHERWISE. RESPONSIBILITY FOR THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE AND SUITABILITY OF ANY SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT RESTS SOLELY WITH THE USER AND THE DIRECT VENDOR, OWNER OR SUPPLIER OF SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT.

Nothing in the Product instructions or information shall be construed to create an express warranty of any kind with respect to the Products. No agent, employee, dealer, representative or reseller is authorized to modify or extend this Limited Warranty or to make binding representations or claims, whether in advertising, presentations or otherwise, on behalf of SAMSUNG regarding the Products or this Limited Warranty.

This Limited Warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

## **What is the procedure for resolving disputes?**

ALL DISPUTES WITH SAMSUNG ARISING IN ANY WAY FROM THIS LIMITED WARRANTY OR THE SALE, CONDITION OR PERFORMANCE OF THE PRODUCTS SHALL BE RESOLVED EXCLUSIVELY THROUGH FINAL AND BINDING ARBITRATION, AND NOT BY A COURT OR JURY.

Any such dispute shall not be combined or consolidated with a dispute involving any other person's or entity's Product or claim, and specifically, without limitation of the foregoing, shall not under any circumstances proceed as part of a class action. The arbitration shall be conducted before a single arbitrator, whose award may not exceed, in form or amount, the relief allowed by the applicable law. The arbitration shall be conducted according to the American Arbitration Association (AAA) Commercial Arbitration Rules applicable to consumer disputes. This arbitration provision is entered pursuant to the Federal Arbitration Act. The laws of the State of Texas, without reference to its choice of laws principles, shall govern the interpretation of the Limited Warranty and all disputes that are subject to this arbitration provision. The arbitrator shall decide all issues of interpretation and application of this arbitration provision and the Limited Warranty.



For any arbitration in which your total damage claims, exclusive of attorney fees and expert witness fees, are \$5,000.00 or less ("Small Claim"), the arbitrator may, if you prevail, award your reasonable attorney fees, expert witness fees and costs as part of any award, but may not grant SAMSUNG its attorney fees, expert witness fees or costs unless it is determined that the claim was brought in bad faith. In a Small Claim case, you shall be required to pay no more than half of the total administrative, facility and arbitrator fees, or \$50.00 of such fees, whichever is less, and SAMSUNG shall pay the remainder of such fees. Administrative, facility and arbitrator fees for arbitrations in which your total damage claims, exclusive of attorney fees and expert witness fees, exceed \$5,000.00 ("Large Claim") shall be determined according to AAA rules. In a Large Claim case, the arbitrator may grant to the prevailing party, or apportion among the parties, reasonable attorney fees, expert witness fees and costs. Judgment may be entered on the arbitrator's award in any court of competent jurisdiction.

This arbitration provision also applies to claims against SAMSUNG's employees, representatives and affiliates if any such claim arises from the Product's sale, condition or performance.

You may opt out of this dispute resolution procedure by providing notice to SAMSUNG no later than 30 calendar days from the date of the first consumer purchaser's purchase of the Product. To opt out, you must send notice by e-mail to [optout@sta.samsung.com](mailto:optout@sta.samsung.com), with the subject line: "Arbitration Opt Out." You must include in the opt out e-mail (a) your name and address; (b) the date on which the Product was purchased; (c) the Product model name or model number; and (d) the IMEI or MEID or Serial Number, as applicable, if you have it (the IMEI or MEID or Serial Number can be found (i) on the Product box; (ii) on the Product information screen, which can be found under "Settings;" (iii) on a label on the back of the Product beneath the battery, if the battery is removable; and (iv) on the outside of the Product if the battery is not removable). Alternatively, you may opt out by calling 1-888-987-4357 no later than 30 calendar days from the date of the first consumer purchaser's purchase of the Product and providing the same information. These are the only two forms of notice that will be effective to opt out of this dispute resolution procedure. Opting out of this dispute resolution procedure will not affect the coverage of the Limited Warranty in any way, and you will continue to enjoy the benefits of the Limited Warranty.

## **Severability**

If any portion of this Limited Warranty is held to be illegal or unenforceable, such partial illegality or unenforceability shall not affect the enforceability of the remainder of the Limited Warranty.

## **Precautions for Transfer and Disposal**

If data stored on this device is deleted or reformatted using the standard methods, the data only appears to be removed on a superficial level, and it may be possible for someone to retrieve and reuse the data by means of special software.

To avoid unintended information leaks and other problems of this sort, it is recommended that the device be returned to Samsung's Customer Care Center for an Extended File System (EFS) Clear which will eliminate all user memory and return all settings to default settings.

Please contact the **Samsung Customer Care Center** for details.

**Important!** Please provide warranty information (proof of purchase) to Samsung's Customer Care Center in order to provide this service at no charge. If the warranty has expired on the device, charges may apply.

No reproduction in whole or in part allowed without prior written approval. Specifications and availability subject to change without notice.  
[010115]

Bluetooth® es una marca comercial registrada de Bluetooth SIG, Inc. en todo el mundo.

- Lea este manual antes de utilizar el dispositivo a fin de garantizar el uso correcto y seguro.
- Es posible que las imágenes no sean exactamente iguales al producto real. El contenido está sujeto a cambio sin previo aviso. Podrá acceder al manual del usuario completo para obtener más información. Ingrese en [www.samsung.com](http://www.samsung.com) para ver datos sobre el dispositivo, el manual del usuario y muchas cosas más.

## Diseño del dispositivo

<b>a</b>	Puerto del cargador	<b>g</b>	Botón Multifunción/ Hablar
<b>b</b>	Micrófono	<b>h</b>	Interruptor de encendido/apagado
<b>c</b>	Correa para el cuello (área de vibración)	<b>i</b>	Anillo de goma
<b>d</b>	Botón Volumen	<b>j</b>	Auricular izquierdo
<b>e</b>	Luz de notificaciones	<b>k</b>	Auricular derecho
<b>f</b>	Imán		

## Carga de la batería

Antes de usar el auricular por primera vez, deberá cargar la batería.

Abra la cubierta del puerto de carga y conecte el auricular a una computadora o al adaptador de corriente USB con el cable USB.



- Podrá cargar el auricular con el cargador (que se vende por separado).
- El cargador deberá permanecer cerca de la toma eléctrica, y deberá poder acceder a él fácilmente mientras el dispositivo se esté cargando.

## Encendido y apagado del auricular

Deslice el interruptor de encendido para apagar el auricular.



Al encender el auricular por primera vez, este ingresará en el modo de vinculación Bluetooth.

## Conexión de dispositivos mediante Bluetooth

Podrá recibir llamadas entrantes o escuchar archivos multimedia cuando auricular esté conectado con dispositivos habilitados para Bluetooth.

1. Encienda el auricular, y luego mantenga presionado el botón Multifunción durante aproximadamente tres segundos para ingresar en el modo de vinculación Bluetooth.  
La luz de notificaciones parpadeará en color rojo y azul.
2. En el otro dispositivo, active la función Bluetooth y toque **Samsung Level U** en la lista.

## **Conexión de dispositivos adicionales**

El auricular puede conectarse con hasta dos dispositivos habilitados para Bluetooth a la vez. Para obtener más información, consulte el manual del usuario.

## **Información sobre seguridad**

Lea toda la información sobre seguridad antes de utilizar el dispositivo a fin de garantizar el uso correcto y seguro. Para ver la información completa sobre seguridad, consulte el sitio web de Samsung.

**Los auriculares contienen imanes. La Asociación Americana del Corazón (Estados Unidos) y la Agencia Regulatoria de Medicamentos y Productos para el Cuidado de la Salud (Reino Unido) advierten que los imanes pueden afectar el funcionamiento de marcapasos, cardioversores, desfibriladores, bombas de insulina u otros dispositivos médicos electrónicos implantados (en conjunto llamados “dispositivos médicos”) dentro del rango de 15 cm (6 pulgadas). Si usted cuenta con alguno de estos dispositivos médicos, NO UTILICE EL AURICULAR A MENOS QUE HAYA CONSULTADO CON SU MÉDICO**

**Use baterías, cargadores, accesorios y suministros aprobados por el fabricante**

**No toque el dispositivo con las manos mojadas**

**No deje caer ni cause un impacto al cargador o al dispositivo**

**No doble ni gire el dispositivo en forma excesiva**

**No guarde el dispositivo en lugares muy cálidos o muy fríos. Se recomienda utilizar el dispositivo en temperaturas de entre 5 °C y 35 °C**

**No permita que los niños o las mascotas muerdan o laman el dispositivo**

**No desarme, modifique ni repare el dispositivo**

**No utilice un auricular mientras conduce o monta. Si lo hace, podría distraerse y provocar un accidente, o podría incurrir en acciones ilegales, según su región**



A fin de evitar posibles daños auditivos al usar un auricular, no escuche sonidos con volumen alto durante mucho tiempo.

**Este producto contiene sustancias químicas que el Estado de California sabe que son causantes de cáncer y toxicidad reproductiva. Para obtener más información, sírvase llamar al 1-800-SAMSUNG (726-7864)**

## **Reciclaje directo**

Para desechar electrónicos correctamente, siga el proceso de reciclaje regulado en su área o visite el sitio web de Samsung para encontrar el establecimiento de reciclaje más cercano:

*[www.samsung.com/recyclingdirect](http://www.samsung.com/recyclingdirect)*

o llame al (877) 278 – 0799.

## **Samsung Electronics America, Inc**

85 Challenger Road,

Ridgefield Park, New Jersey, 07660

Teléfono: 1-800-SAMSUNG (726-7864)

