

Reset Powerbeats Wired

Hold down both the power button and volume down button for 10 seconds. When the LED indicator light flashes, release the buttons. Your earphones are now **reset** and ready to be set up with your devices again.

