

# Reset Solo<sup>3</sup> Wireless headphones

1.

## *Reset*

1. Hold down these two buttons for 10 seconds:
  - Power button
  - Volume down button
2. When the Fuel Gauge flashes, release the buttons. Your headphones are now reset and ready to be [set up with your devices](#) again.

2.

## *Update*

Your headphones are automatically kept up to date when they're set up with an iPhone using iOS 10 or later.

