

Resetting your headphones Around Ear Series 2

Applies to:

Around Ear Series 2

Resetting your Bluetooth® headphones can help fix minor issues, such as a poor connection, sound issues, or streaming performance.

Follow these steps to reset the headphones:

1. Turn the headphones off and wait for 30 seconds
2. Plug the headphones into a USB power supply via a USB cord and wait 5 seconds. (Power supply needs to be plugged into a working outlet)
3. Unplug the USB cord from the headphones and wait 1 minute
4. Turn the headphones on and test if they work properly

Note: Performing this reset does not clear the pairing list on your headphones.

Clearing the headphone pairing list

Power off the headphones

Press and hold the **Power/Bluetooth®** button for 10 seconds, until you hear "Bluetooth device list cleared" Delete your Bose Around Ear Series 2 headphones

from the *Bluetooth* list on your device. All devices are cleared and the headphones are ready to pair a new device