

Voyager Edge Series Reset

Reset Sensors You may need to reset the sensors if they are not working as expected. • Wearing the headset, tap the Call button to test sensors. A talk time voice alert means sensors are working. A tone or lack of voice prompts means sensors need to be reset. •

To **reset** your sensors, connect the headset directly to your computer's USB port, and place it, with the eartip up, on a flat non-metallic surface for more than 10 seconds. To disable the sensors, hold both the Voice and Call buttons for more than 6 seconds until the LED flashes purple then red.

